



Piezoelectric Paper: Characterization and Sensor Application

UBC Mechanical Engineering Department

Peter Lin



Outline

- Background – Piezoelectric materials
- Research on fiber content and fines effect on material properties
 - Introduction
 - Materials – Two type of piezoelectric papers
 - Method – Dynamic mechanical analysis (DMA)
 - Results – Fiber content effect on modulus
- Applications – Accelerometer
- Future Research Plan — Characterize electromechanical properties

Background Piezoelectric Materials



Piezoelectric Materials

Piezoelectric Effect Principle


- Positive and negative charges at different centers
- Dipole moments under loading
- Electro-mechanical Coupling
- Reverse piezoelectric effect

Piezoelectric Coefficient


- Strength of piezoelectric response
- Induced charge / Applied force

Applications

- Piezoelectric Effect – force and acceleration sensors
- Reverse piezoelectric effect – actuators and speakers



Piezoelectric effect



Reverse Piezoelectric effect

Research on Fiber Content and Fines Effect



Introduction

Piezoelectric papers

- Flexible and sustainable piezoelectric materials (Mahadeva et al., 2016)
- Research gaps on piezoelectric papers


Our Research

- Study fiber content and fines' effect on material properties




Materials


- Paper substrate with:
 - A. Pulp
 - B. Pulp and Fines, enhance strength
- 300nm BaTiO₃ particles loaded on the papers, 69wt%




Paper with Pulp in 100 μm scale



Paper with Pulp in 10 μm scale



Paper with Pulp and Fines in 100
μm Scale




Paper with Pulp and Fines in 10
μm Scale



Equipment and Method

- **Dynamic Mechanical Analysis**
 - What is that?
 - A technology to analyze materials' kinetic properties by applying stress or strain.
 - How it works in our experiment?
 - Applying sinusoidal force
 - Measure the sample displacement
 - Applications in measuring:
 - Modulus
 - Viscosity




DMA Machine, DMA 8000



Equipment and Method


- **Test Method**
 - 5mm by 5mm paper sample
 - Applying loading at:
 - A. 2 to 4 N (tensile)
 - B. 2 to 10 N (compressive)
 - Generate the stress-strain plot
 - Slope is calculated as Young's modulus
 - Piezoelectric Coefficient
 - Piezoelectric coefficient meter.



Compressive Stress-strain Plot for A4
Printing Paper




Results



Paper	A	B	C	D	E	F	G	H
Component	300 ml Pulp	400 ml Pulp	500 ml Pulp	600 ml Pulp	700 ml Pulp	400 ml Pulp + 25 ml Fines	400 ml Pulp + 50 ml Fines	400 ml Pulp + 75 ml Fines
Thickness [mm]	0.06	0.07	0.08	0.139	0.206	0.152	0.154	0.18



Results




Paper	A	B	C	D	E	F	G	H
Component	300 ml Pulp	400 ml Pulp	500 ml Pulp	600 ml Pulp	700 ml Pulp	400 ml Pulp + 25 ml Fines	400 ml Pulp + 50 ml Fines	400 ml Pulp + 75 ml Fines
Thickness [mm]	0.06	0.07	0.08	0.139	0.206	0.152	0.154	0.18

Application - Accelerometer



Paper Based Accelerometer

Accelerometer Prototype






Validation


Paper Sensor

Arduino Accelerometer






Validation



Application - Speaker



Paper Based Speaker




Source: <https://www.bestbuy.ca/en-ca/product/marshall-mg-gold-30w-guitar-combo-amp-with-digital-effects-mg30gfx/15316151>




Paper Based Speaker

Original Sound is noisy

- Low pass filter to control noise from paper itself
- High pass filter to reduce environmental noise (Mostly fan and HVAC)



Low Pass Filter




High Pass Filter




Paper Based Speaker

Lighter color means higher amplitude

Before applying filters



After applying filters



Future Research Plan



Future Research Plan

Our Plan

- Test electro-mechanical properties of different papers with different size of BTO particles

Acknowledgement



Acknowledgement

- Kanagasubbulakshmi Sankaralingam, Sajana Sumanasinghe, Ninweh Nina Jeorje, Anindya L. Roy, and Vishesh Jung Thapa for collecting the data and explaining how to use the devices.
- Prof. Boris Stoeber and Prof. Konrad Walus for reviewing and providing feedback on our results
- CREAT-U program and Canfor for funding our research.

Thank You & Questions